

Weekly Chlorine Free Cold Wash Programme for Milking Plant

CirCool L / CirCool P / Circo-Acid 3 and Serpent



For best results Biocel recommend that a Luke warm pre-rinse –(30 -35 C) is done directly after milking before all detergent washes
Hot Acid Circulation (Circo-Acid 3) be done at 60-70°C on 2 days per week after Cold CirCool wash and prior to next milking

DAY	Morning	Evening
DAY 1	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse
DAY 2	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse
DAY 3	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse
DAY 4	Cold Detergent Circulation CirCool L / CirCool P Hot Acid Descaler Circulation Circo Acid 3 Send to drain after use. Serpent added to final rinse	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse
DAY 5	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse
DAY 6	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse
DAY 7	Cold Detergent Circulation CirCool L / CirCool P Hot Acid Descaler Circulation Circo Acid 3 Send to drain after use. Serpent added to final rinse	Cold Detergent Circulation CirCool L / CirCool P Send to drain after use. Serpent added to final rinse